

FLAT DOOR STAND INSTALL INSTRUCTIONS



Tools For The Job

- Measuring Tape
- Black Wood
- Drill
- Screws

STEP 1

Measure out the height of the door frame, from floor to frame height.
Cut the black wood to this height.

STEP 2

Use one or two pieces of black wood per side (Depending on the brickmould option). You want it to be near flush on either side with the edge of the brickmould. If using two pieces of wood, connect them together with two screws.

STEP 3

Screw the door to the wood through the prep holes in the door frame. The prep holes are located under the weather stripping.

STEP 4

Screw the display stand to the door from the exterior, into the pieces of black wood.

We are here to help!

*Don't hesitate to reach out with any questions or concerns.
If you require any other showroom updates please contact
your rep, who would be happy to assist you.*



Yesterday. Today. Tomorrow. Outstanding.